

I'm not a bot



Page 2
3Power Supply 110-120 V / 60 Hz venience of having to pre-freeze the mixing bowl. Not only is it so much easier, it also tastes a Self-contained frozen dessert maker that does not require pre-freezing Removable stainless steel mixing bowl and BPA-free churn blade for easy storage and Page 4 Plug into a grounded 3-prong outlet, do not remove grounding prong, do not use an extension cord. Do not use the power supply cord if damaged. It must be replaced by a qualified electrician. It is recommended that a separate circuit be provided for your appliance. These fumes can create a fire. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of the appliance or Before proceeding with cleaning and maintenance operations, make sure to unplug the appliance. To protect against risk of electric shock, do not pour water on cord, plug and ventilation, immerse the Do not attempt to repair or replace any part of your appliance unless it is specifically recommended in Page 5 It is important for the appliance to be leveled in order to work properly. For a stable installation, When positioning or moving the appliance ensure that it is not turned upside down or greater than To ensure proper ventilation for your appliance, the air vents of the appliance must be completely This appliance is not intended for use by young children or physically-challenged persons without Never pull the cord to disconnect it from the outlet. Grasp the plug and pull it from the outlet. This appliance is designed for household, non-commercial use only. Any other use will void the Do not power on the appliance before the removable mixing bowl and transparent lid are installed This is a self-contained ice cream maker and no pre-freezing is needed. Do not use pre-frozen This is an electrical appliance, to avoid injury from electrical shock do not operate the unit with Page 6 Before connecting the appliance to the power source, let it stand upright for approximately 2 hours. This will Wash all parts that will come into contact with the ice cream (including the removable mixing bowl, churn Note: No pre-freezing is needed. This appliance has a built-in compressor which is designed to freeze the mix-ice Cream Recipes can be downloaded from the ICM-2015B product page on our website, www.whynter.com or Page 77 INSTALLATION OF YOUR APPLIANCE WARNING: Do not store or install the appliance outdoors. CAUTION: This appliance is designed for making ice cream desserts. Place your appliance on a hard and level surface that is strong enough to support it when ingredients are added. Allowance of at least 5 inches (127mm) of space around the appliance is suggested, which allows the proper air circulation to cool the compressor and condenser. Do not install the appliance near an oven or other heating source. Plug in the appliance into an exclusive, grounded wall power outlet. Do not under any circumstances cut or remove the third (ground) prong from the power cord. Any questions concerning power and/or groundings should be directed toward a qualified electrician or an authorized service center.FREESTANDING INSTALLATION A freestanding installation will allow you to install the ice cream maker in any place you desire provided that the required clearance space around the appliance is respected. In every setting, there must be an adequate ventilation and access for service. Never install or operate the unit in an enclosed area. Allowance of at least 5 inches (127mm) of space around the appliance is suggested, which allows the proper air circulation to cool the compressor and condenser. ELECTRICAL CONNECTION WARNING: Improper use of the grounded plug can result in the risk of electrical shock. If the power cord is damaged, have it replaced by a qualified electrician or contact Whynter Service Department. This appliance requires a standard 115/120 Volt AC ~60Hz electrical ground outlet with three-prong. Have the wall outlet and circuit checked by a qualified electrician to make sure the outlet is properly grounded. The cord should be secured behind the appliance and not left exposed or dangling to prevent accidental injury. The appliance should always be plugged into its own individual electrical outlet which has a voltage rating that matches the rating label on the appliance. This provides the best performance and also prevent overloading house wiring circuits that could cause a fire hazard from overheated. Never unplug the appliance by pulling the power cord. Always grip the plug firmly and pull straight out from the receptacle. Repair or replace immediately all power cords that have become frayed or otherwise damaged. Do not use a cord that shows cracks or abrasion damage along its length or at either end. When moving the appliance, be careful not to damage the power cord. EXTENSION CORD Because of potential safety hazards, it is strongly recommended that you do not use an extension cord with this appliance. However, if you must use an extension cord, it is absolutely necessary that it be a UL/CUL-Listed, 3-wire grounding type appliance extension cord having a grounding type plug and outlet and that the electrical rating of the cord be 115 volts and at least 10 amperes. Read all instructions before using the appliance. DANGER or WARNING: An empty ice cream maker can be a hazardous for children or small pets. If disposing of the ice cream maker, remove mixing bowl, churn blade, or transparent lid from your unused appliance, or take other action to ensure the ice cream maker is harmless. Never allow children to operate or play with the appliance. Never clean appliance parts with flammable fluids or harsh chemicals. The fumes can create a fire hazard or explosion. Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion. Page 81.a)Ice Cream mode - In this mode, the ice cream maker will churn and freeze. The LCD will display 60:00 before starting this mode. An ice cream icon will be displayed when Ice Cream mode (Cooling and Cooling only mode) - In this mode, the ice cream maker will freeze without churning for a defaulted time mode. A snowflake icon will be displayed when Cooling mode is in operation. This mode is ideal for Mixing only mode - In this mode, the churn blade will continue churning for a default time of 10:00 minutes without cooling. This mode is ideal for pre-mixing the prepared ingredients and adding extra fore starting this mode. A mixing icon will be displayed when Mixing mode is in operation. Page 9The operation icon corresponding to the operation mode chosen. The unit can be paused by pressing the2. Prepare ingredients (see pages 11 - 12 of the User Manual for3. Place removable mixing bowl into the base. Be sure bowl is properly aligned. Make sure the outside of the 4. Place churn blade in the removable mixing bowl so that it rests in the center of the bowl.5. Pour mixture into the removable mixing bowl. When mixture is ready, position the transparent lid and lock 7. The timer will default to 60:00 minutes. Timer can be adjusted by pressing the timer button.8. Press the START/PAUSE button to begin. The timer will count down to 00:00 and the unit will beep three Tip: Additional ingredients such as nuts and fruits can be added towards the end of mixing time. Once the 9. Turn the unit off by pressing the POWER button. Remove the transparent lid by turning it clockwise to un-lock. Lift removable mixing bowl out of the base with handle. Remove churn blade from removable mixing Function to keep the ice cream frozen. In this function, the compressor will come on in six minute cycles for two 2.a Page 10• If the unit is paused and operation is not resumed in 10 minutes, the unit will go into Standby mode. The unit may enter a three minute compressor lockout when operation of the unit has been resumed. This threeNOTE: The time it takes to make a batch of ice cream varies and depends on the amount and tem-freshly home-made. For fruit ices, sherbets or ice creams to have a long freezer life, the fruits must be cooked. Page 11Ice cream mixtures can be as simple as pureed fruit, sugar and cream, Philadelphia-style, or based on more recipes which follow are for both kinds. All use rich, heavy cream. If you prefer a lighter, lower-calorie mixture, of chopped nuts, chocolate chips or candy to a quart of mixture either before or after freezing, depending on Page 12Page 13bowl]amentsup Our freezing bowl is approved for food safety. Since aluminum can react to acidic solutions, the recommendation is to not store acidic foods in the freezing bowl for long periods. We recommend removing any acidic frozen dessert maker that does not require pre-freezing Removable stainless steel mixing bowl and BPA-free churn blade for easy storage and Page 4 Plug into a grounded 3-prong outlet, do not remove grounding prong, do not use an adapter, and do not use if the power supply cord is damaged. If damaged, it must be replaced by a qualified electrician. It is recommended that a separate circuit, serving only your appliance be provided. Use receptacles Never clean appliance parts with flammable fluids or harsh chemicals. These fumes can create a fire Do not store or use gasoline or other flammable vapors and liquids in the vicinity of the appliance or Before proceeding with cleaning and maintenance operations, make sure to unplug the appliance. To protect against risk of electric shock, do not pour water on cord, plug and ventilation, immerse the Do not attempt to repair or replace any part of your appliance unless it is specifically recommended in Page 5 It is important for the appliance to be leveled in order to work properly. For a stable installation, When positioning or moving the appliance ensure that it is not turned upside down or greater than To ensure proper ventilation for your appliance, the air vents of the appliance must be completely This appliance is not intended for use by young children or physically-challenged persons without Never pull the cord to disconnect it from the outlet. Grasp the plug and pull it from the outlet. This appliance is designed for household, non-commercial use only. Any other use will void the Do not power on the appliance before the removable mixing bowl and transparent lid are installed This is a self-contained ice cream maker and no pre-freezing is needed. Do not use pre-frozen This is an electrical appliance, to avoid injury from electrical shock do not operate the unit with Page 6 Before connecting the appliance to the power source, let it stand upright for approximately 2 hours. This will Wash all parts that will come into contact with the ice cream (including the removable mixing bowl, churn Note: No pre-freezing is needed. This appliance has a built-in compressor which is designed to freeze the mix-ice Cream Recipes can be downloaded from the ICM-2015B product page on our website, www.whynter.com or Page 77 INSTALLATION OF YOUR APPLIANCE WARNING: Do not store or install the appliance outdoors. CAUTION: This appliance is designed for making ice cream desserts. Place your appliance on a hard and level surface that is strong enough to support it when ingredients are added. Allowance of at least 5 inches (127mm) of space around the appliance is suggested, which allows the proper air circulation to cool the compressor and condenser. Do not install the appliance near an oven or other heating source. Plug in the appliance into an exclusive, grounded wall power outlet. Do not under any circumstances cut or remove the third (ground) prong from the power cord. Any questions concerning power and/or groundings should be directed toward a qualified electrician or an authorized service center.FREESTANDING INSTALLATION A freestanding installation will allow you to install the ice cream maker in any place you desire provided that the required clearance space around the appliance is respected. In every setting, there must be an adequate ventilation and access for service. Never install or operate the unit in an enclosed area. Allowance of at least 5 inches (127mm) of space around the appliance is suggested, which allows the proper air circulation to cool the compressor and condenser. ELECTRICAL CONNECTION WARNING: Improper use of the grounded plug can result in the risk of electrical shock. If the power cord is damaged, have it replaced by a qualified electrician or contact Whynter Service Department. This appliance requires a standard 115/120 Volt AC ~60Hz electrical ground outlet with three-prong. Have the wall outlet and circuit checked by a qualified electrician to make sure the outlet is properly grounded. The cord should be secured behind the appliance and not left exposed or dangling to prevent accidental injury. The appliance should always be plugged into its own individual electrical outlet which has a voltage rating that matches the rating label on the appliance. This provides the best performance and also prevent overloading house wiring circuits that could cause a fire hazard from overheated. Never unplug the appliance by pulling the power cord. Always grip the plug firmly and pull straight out from the receptacle. Repair or replace immediately all power cords that have become frayed or otherwise damaged. Do not use a cord that shows cracks or abrasion damage along its length or at either end. When moving the appliance, be careful not to damage the power cord. EXTENSION CORD Because of potential safety hazards, it is strongly recommended that you do not use an extension cord with this appliance. However, if you must use an extension cord, it is absolutely necessary that it be a UL/CUL-Listed, 3-wire grounding type appliance extension cord having a grounding type plug and outlet and that the electrical rating of the cord be 115 volts and at least 10 amperes. Read all instructions before using the appliance. DANGER or WARNING: An empty ice cream maker can be a hazardous for children or small pets. If disposing of the ice cream maker, remove mixing bowl, churn blade, or transparent lid from your unused appliance, or take other action to ensure the ice cream maker is harmless. Never allow children to operate or play with the appliance. Never clean appliance parts with flammable fluids or harsh chemicals. The fumes can create a fire hazard or explosion. Page 81.a)Ice Cream mode - In this mode, the ice cream maker will churn and freeze. The LCD will display 60:00 before starting this mode. An ice cream icon will be displayed when Ice Cream mode (Cooling and Cooling only mode) - In this mode, the ice cream maker will freeze without churning for a defaulted time mode. A snowflake icon will be displayed when Cooling mode is in operation. This mode is ideal for Mixing only mode - In this mode, the churn blade will continue churning for a default time of 10:00 minutes without cooling. This mode is ideal for pre-mixing the prepared ingredients and adding extra fore starting this mode. A mixing icon will be displayed when Mixing mode is in operation. Page 9The operation icon corresponding to the operation mode chosen. The unit can be paused by pressing the2. Prepare ingredients (see pages 11 - 12 of the User Manual for3. Place removable mixing bowl into the base. Be sure bowl is properly aligned. Make sure the outside of the 4. Place churn blade in the removable mixing bowl so that it rests in the center of the bowl.5. Pour mixture into the removable mixing bowl. When mixture is ready, position the transparent lid and lock 7. The timer will default to 60:00 minutes. Timer can be adjusted by pressing the timer button.8. Press the START/PAUSE button to begin. The timer will count down to 00:00 and the unit will beep three Tip: Additional ingredients such as nuts and fruits can be added towards the end of mixing time. Once the 9. Turn the unit off by pressing the POWER button. Remove the transparent lid by turning it clockwise to un-lock. Lift removable mixing bowl out of the base with handle. Remove churn blade from removable mixing Function to keep the ice cream frozen. In this function, the compressor will come on in six minute cycles for two 2.a Page 10• If the unit is paused and operation is not resumed in 10 minutes, the unit will go into Standby mode. The unit may enter a three minute compressor lockout when operation of the unit has been resumed. This threeNOTE: The time it takes to make a batch of ice cream varies and depends on the amount and tem-freshly home-made. For fruit ices, sherbets or ice creams to have a long freezer life, the fruits must be cooked. Page 11Ice cream mixtures can be as simple as pureed fruit, sugar and cream, Philadelphia-style, or based on more recipes which follow are for both kinds. All use rich, heavy cream. If you prefer a lighter, lower-calorie mixture, of chopped nuts, chocolate chips or candy to a quart of mixture either before or after freezing, depending on Page 12Page 13bowl]amentsup Our freezing bowl is approved for food safety. Since aluminum can react to acidic solutions, the recommendation is to not store acidic foods in the freezing bowl for long periods. We recommend removing any acidic frozen dessert maker that does not require pre-freezing Removable stainless steel mixing bowl and BPA-free churn blade for easy storage and effortless cleaning Reliable built-in audible timer Motor Protection Function that shuts off to prevent damage if the mixture freezes solid LCD timer control High efficiency CFC-free compressor ETL Certified TECHNICAL DATA MODEL ICM-2015B Capacity 2.1 Quart / 2 Liter Power Supply 110-120 V / 60 Hz Maximum power consumption 180W Cooling Temperature -0.4F to -31F Refrigerant R134a Noise Level < 58dB Net Weight 24.25 lbs Unit Dimensions 12.5" W x 10.75" D x 14.25" H Packaging Dimensions 14" W x 12.75" D x 19.5" H Features and Parts BEFORE USING YOUR APPLIANCE Remove the exterior and interior packing. Before connecting the appliance to the power source, let it stand upright for approximately 2 hours. This will reduce the possibility of a malfunction in the cooling system from handling during transportation. Clean the interior surface with lukewarm water using a soft cloth. Wash all parts that will come into contact with the ice cream (including the removable mixing bowl, churn blade, transparent lid, measuring cup and scoop). Note: Please note that the parts are not dishwasher safe. PREPARE RECIPE INGREDIENTS Prepare recipe ingredients from your own recipe or from ours, and pour the mixture into the removable mixing bowl. Note: No pre-freezing is needed. This appliance has a built-in compressor which is designed to freeze the mixture in between 30:00 - 60:00 minutes. Ice Cream Recipes can be downloaded from the ICM-2015B product page on our website, www.whynter.com or just send us an email at support@whynter.com and we will send you a guide to introduce you to a variety of mixtures, ice creams, frozen yogurts, sherbets, and sorbets which will open up a world of possibilities to explore, and once you have mastered the basics, let your imagination run wild, as you try new flavors and fun combinations. IMPORTANT SAFETY INSTRUCTIONS To reduce the risk of fire, electrical shock, or injury when using your appliance, follow these basic precautions: Read all instructions before using the appliance. or An empty ice cream maker can be a hazardous for children or small pets. If disposing of the ice cream maker, remove mixing bowl, churn blade, or transparent lid from your unused appliance, or take other action to ensure the ice cream maker is harmless. Never allow children to operate or play with the appliance. Never clean appliance parts with flammable fluids or harsh chemicals. The fumes can create a fire hazard or explosion. Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion. INSTALLATION OF YOUR APPLIANCE Do not store or install the appliance outdoors. This appliance is designed for making ice cream desserts. Place your appliance on a hard and level surface that is strong enough to support it when ingredients are added. Allowance of at least 5 inches (127mm) of space around the appliance is suggested, which allows the proper air circulation to cool the compressor and condenser. Do not install the appliance near an oven or other heating source. Plug in the appliance into an exclusive, grounded wall power outlet. Do not under any circumstances cut or remove the third (ground) prong from the power cord. Any questions concerning power and/or grounding should be directed toward a qualified electrician or an authorized service center. FREESTANDING INSTALLATION A freestanding installation will allow you to install the ice cream maker in any place you desire provided that the required clearance space around the appliance is respected. In every setting, there must be an adequate ventilation and access for service. Never install or operate the unit in an enclosed area. Allowance of at least 5 inches (127mm) of space around the appliance is suggested, which allows the proper air circulation to cool the compressor and condenser. ELECTRICAL CONNECTION WARNING: Improper use of the grounded plug can result in the risk of electrical shock. If the power cord is damaged, have it replaced by a qualified electrician or contact Whynter Service Department. This appliance requires a standard 115/120 Volt AC ~60Hz electrical ground outlet with three-prong. Have the wall outlet and circuit checked by a qualified electrician to make sure the outlet is properly grounded. The cord should be secured behind the appliance and not left exposed or dangling to prevent accidental injury. The appliance should always be plugged into its own individual electrical outlet which has a voltage rating that matches the rating label on the appliance. This provides the best performance and also prevent overloading house wiring circuits that could cause a fire hazard from overheated. Never unplug the appliance by pulling the power cord. Always grip the plug firmly and pull straight out from the receptacle. Repair or replace immediately all power cords that have become frayed or otherwise damaged. Do not use a cord that shows cracks or abrasion damage along its length or at either end. When moving the appliance, be careful not to damage the power cord. EXTENSION CORD Because of potential safety hazards, it is strongly recommended that you do not use an extension cord with this appliance. However, if you must use an extension cord, it is absolutely necessary that it be a UL/CULListed, 3-wire grounding type appliance extension cord having a grounding type plug and outlet and that the electrical rating of the cord be 115 volts and at least 10 amperes. INSTALLATION OF YOUR APPLIANCE NOTE: Always place the Ice Cream Maker upright on a flat, level and solid surface. Install the removable mixing bowl into the motor axis. Make sure the outside of the removable mixing bowl is completely dry before inserting it to the appliance. (See 1.a) Insert the removable mixing bowl. (See 1.b) Install the transparent lid on top of the bowl and lock it by turning it counterclockwise. COLLECT POWER Button After the appliance is installed and connected to the power supply, press the Power button to turn the machine on. The LCD will display "60:00" which is the factory preset 60 minutes operating time. When the unit is on and the Power button is pressed, the unit will enter Standby mode until the power cord is unplugged. NOTE: If the POWER button is pressed at any point of the ice cream making operation, the unit will be turned off and will automatically reset/cancel the ice cream making process. MENU Button This unit can be operated in three convenient modes: Ice Cream mode - In this mode, the ice cream maker will churn and freeze. The LCD will display 60:00 minutes as its default operating time. The desired time can be adjusted by pressing the Timer button before starting this mode. An ice cream icon will be displayed when Ice Cream mode (Cooling and Mixing) is in operation. Cooling only mode - In this mode, the ice cream maker will freeze without churning for a defaulted time of 30:00 minutes. The desired time can be adjusted by pressing the Timer button before starting this mode. A snowflake icon will be displayed when Cooling mode is in operation. This mode is ideal for preventing the frozen ice cream from melting. Mixing only mode - In this mode, the churn blade will continue churning for a default time of 10:00 minutes without cooling. This mode is ideal for pre-mixing the prepared ingredients and adding extra ingredients to the finished mixture. The desired time can be adjusted by pressing the Timer button before starting this mode. A mixing icon will be displayed when Mixing mode is in operation. NOTE: When the Menu button is pressed down for more than 3 seconds, the ice cream maker will return to setup screen and cancels the current operation. START / PAUSE Button After desired operating time is set, press the START/PAUSE button to initiate operation. The LCD will display the operation icon corresponding to the operation mode chosen. The unit can be paused by pressing the START/PAUSE again. At pause, press START/PAUSE button and the machine will resume its unfinished operation. NOTE: The unit may enter a three minute compressor lockout when operation of the unit has been resumed. This three minute time delay helps extend the life of the compressor. During the compressor lockout, only the Mixing only icon will be displayed. Once it elapses, the compressor will engage, ice cream icon will be displayed, and the ice cream maker will start cooling again. TIMER Button Operation time can be selected by pressing the Timer Button in 1:00 minute increments. Pressing the timer button will increase the operation time starting from the 05:00 minute mark up to 60:00 minute mark. ICE CREAM MAKING Before first use, wipe the base of the unit with a moist cloth. Do not immerse the base in water. Wash the lid, removable mixing bowl and churn blade in warm, soapy water to remove any dust or residue from the manufacturing and shipping process. Please note that the parts are not dishwasher safe. Do not clean any of the parts with abrasive cleaners or hard implements. OPERATING INSTRUCTIONS Plug the unit into the power outlet. LCD screen will display "00" for standby. Prepare ingredients (see the User Manual for recipes). Note: Please make sure that the pre-mix does not exceed the top dasher of the churn blade to avoid overflowing. See 2.a Place removable mixing bowl into the base. Be sure bowl is properly aligned. Make sure the outside of the mixing bowl is completely dry before inserting it into the appliance. Place churn blade in the removable mixing bowl so that it rests in the center of the bowl. Pour mixture into the removable mixing bowl. When mixture is ready, position the transparent lid and lock into place by turning it counterclockwise. Press the POWER button to turn the unit on. The timer will default to 60:00 minutes. Timer can be adjusted by pressing the timer button. Press the START/PAUSE button to begin. The timer will count down to 00:00 and the unit will beep three times to indicate the mixture is ready Tip: Additional ingredients such as nuts and fruits can be added towards the end of mixing time. Once the mixture has begun to thicken (usually about 5 minutes from end time), add the ingredients. Turn the unit off by pressing the POWER button. Remove the transparent lid by turning it clockwise to unlock. Lift removable mixing bowl out of the base with handle. Remove churn blade from removable mixing bowl. NOTE: If the unit is not powered off and removable mixing bowl is not removed from the unit after the operation time, it will go into an Extended Cooling Function. EXTENDED COOLING FUNCTION When the set operation time has elapsed (LCD displays "00:00"), the operation stops and the appliance will beep 3 times. If the appliance is not turned off in ten minutes, it automatically enters into an Extended Cooling Function to keep the ice cream frozen. In this function, the compressor will come on in six-minute cycles for two hours. When done, the unit will beep 5 times to note that the Extended Cooling Function has completed. The unit will go into Standby mode afterwards. NOTE: The mixing function is not activated during the Extended Cooling Function. If you would like to mix as well, press and hold the Menu button for 3 seconds to reset. You can also turn the unit off at any time during the Extended Cooling Function. PAUSE TIME AND MIXING Press the START/PAUSE button at any point of the ice cream making operation to pause the time and mixing. The ice cream maker will still keep cooling the mixture. Press the START/PAUSE button again to resume operation. NOTE: If the unit is paused and operation is not resumed in 10 minutes, the unit will go into Standby mode. The unit may enter a three minute compressor lockout when operation of the unit has been resumed. This three minute time delay helps extend the life of the compressor. Once elapses, the compressor will engage and the ice cream maker will start cooling again. ADJUSTING OPERATIONS Increasing/Decreasing Operation Time during Operation If changing of operation time is needed, press the Start/Pause button to pause unit. To adjust operation time, press the Timer button. Operation Time adjustment will be in 1:00 minute increments. Motor Protection Function When the mixture becomes hard, the motor's protection device stops the motor from churning to prevent overheating or damage to the motor. Controlling the Volume of the Ingredients To avoid overflowing, please ensure that the mixture does not exceed 60% of capacity of the removable mixing bowl as frozen mixture expands. NOTE: The time it takes to make a batch of ice cream varies and depends on the amount and temperature of the ingredients used. For quicker results, use less ingredients and/or refrigerated ingredients. STORAGE OF ICE CREAM Remove the frozen mixture or finished ice cream into a clean and dry container using the plastic scoop. Do not use metal scoops as it can scratch the removable mixing bowl. Fruit based ice creams, sorbets and sherbets are only truly delicious when they have the just picked flavor that time so rapidly destroy. That is why no commercial fruit ices, sherbets or ice creams can ever be as good as freshly home-made. For fruit ices, sherbets or ice creams to have a long freezer life, the fruits must be cooked, thereby destroying their freshness. If your creations are consumed in a short time frame, you can use uncooked fruit purees for a much better flavor. Recipes Ice cream mixtures can be as simple as pureed fruit, sugar and cream, Philadelphia-style, or based on more complicated cooked custards, French style. Are delicious, though French versions are slightly richer. The recipes which follow are for both kinds. All use rich, heavy cream. If you prefer a lighter, lower-calorie mixture, substitute milk (whole or skim) or even yogurt for the cream in any of these recipe. Always sample the mixtures before freezing and adjust to your own taste. Use these simple recipes as an inspiration for your own favorite ice creams. If you like a little crunch, add a cup of chopped nuts, chocolate chips or candy to a quart of mixture either before or after freezing, depending on whether you want the crunch to be frozen, too. You can also add chopped fruit, fresh or dried, shredded coconut, even marshmallows. It's better to add these soft things at the end so they do not get icy. Strawberry Ice Cream 2 pints strawberries, washed and hulled ¼ cup plus 2 tablespoons superfine sugar 3 tablespoons fresh lemon juice 1 ½ cups heavy cream Purée the strawberries in a food processor. Stir in the remaining ingredients. Pour the mixture into the removable mixing bowl of the ice cream maker and freeze. Maple Walnut Ice Cream 2 cups heavy cream ¾ cup milk 1 ¼ cups Vermont grade maple syrup ¾ cup walnut pieces Pour the mixture into the bowl of the SNO ice cream maker and freeze. Peach Ice Cream 20 16-ounce can peaches packed in heavy syrup, drained, liquid discarded. ¾ cup simple syrup 3 tablespoons fresh lemon juice 1 cup heavy cream Puree the peaches in a food processor. Add the syrup, lemon juice and cream. Pour the mixture into the removable mixing bowl of the ice cream maker and freeze. Coconut Ice Cream 15-ounce can sweeten cream of coconut. 1 cup milk 1 ½ cups heavy cream ½ cup tightly-packed sweetened coconut flakes Place the coconut cream and milk in a food processor and blend thoroughly. Stir in the cream and coconut flakes. Pour the mixture into the removable mixing bowl of the ice cream maker and freeze. Chocolate Ice Cream 3 ounces semisweet chocolate 1 ounce unsweetened chocolate 1 recipe Custard Ice Cream Base, warm Melt the chocolate together in a saucepan over low heat, stirring occasionally until smooth. Gradually add some of the ice cream base to the chocolate, whisking it frequently to keep the chocolate smooth. Add the remaining ice cream base and cook over low heat until the mixture is well blended. Cook thoroughly. Pour the mixture into the removable mixing bowl of the ice cream maker and freeze. Rich Vanilla Ice Cream 3 cups heavy cream 1 cup whole milk ½ cup sugar 2 vanilla beans, split, or 2 tablespoons vanilla extract 4 egg yolks Follow the recipe for the Custard Ice Cream Base, adding the vanilla beans to the saucepan with the cream, milk and sugar. Just before straining, scrape the seeds from the beans into the custard base. If using vanilla extract, add to the base after straining. Pour the mixture into the removable mixing bowl of the ice cream maker and freeze. Fresh Strawberry Sorbet 2 pints strawberries, washed and hulled 1 cup plus 2 tablespoons simple syrup ¼ cup fresh lemon juice Purée the strawberries in a food processor. You should have about 3 ½ cups. Stir in the simple syrup and lemon juice. Force the mixture through a fine sieve. Pour the mixture into the removable mixing bowl of the ice cream maker and freeze. Fresh Pineapple Sorbet 1 small ripe Hawaiian pineapple 1 cups simple syrup 2 tablespoons fresh lemon juice Peel, core and cube the pineapple. Place the cubes in a food processor and process until very smooth and frothy. You should have 2 ½ cups. Stir in the simple syrup and lemon juice. Taste and add more syrup or juice if needed. Pour the mixture into the removable mixing bowl of the ice cream maker and freeze. Strawberry Daiquiri 2 pints strawberries, washed and hulled ½ cup superfine sugar ½ cup fresh lemon or lime juice 1 1/3 cups rum Purée the strawberries in a food processor. Place the puree in the bowl of the machine with the remaining ingredients and freeze 25 to 30 minutes, depending on how firm you like your drinks. Serves 6. Frozen Margarita ¾ cup tequila ¼ cup triple sec 1 cup fresh lemon or lime juice ¼ cup water Power all the ingredients into the bowl of the machine and freeze 15 to 20 minutes, depending on how firm you like your drinks. While the mixtures is freezing, rub the rims of 6 glasses with a lemon wedge. Dip the rims in salt. Serve the drinks in the salted glasses. Serves 6. Pina Colada One 20-ounce can crushed pineapple, drained 1 cup coconut cream 4 dashes bitters ¼ teaspoon salt 1 cup water 1 cup rum Purée the pineapple in a food processor. You should have about 1 ½ cups of puree. Place the puree in the bowl of the machine with the remaining ingredients and freeze 25 to 30 minutes depending on how firm you like your drinks. Serves 6. Banana Daiquiri One 20-ounce can crushed pineapple, drained 1 cup coconut cream 4 dashes bitters ¼ teaspoon salt 1 cup water 1 cup rum Purée the pineapple in a food processor. You should have about 1 ½ cups of puree. Place the puree in the bowl of the machine with the remaining ingredients and freeze 25 to 30 minutes depending on how firm you like your drinks. Serves 6. Many common ice cream maker problems are easily resolved. Try the troubleshooting suggestions below to see if the problems can be resolved before having to contact the Whynter Service Department. Problem Possible Causes Solutions Power off the unit and wait for the mixture to be soften Room's ambient temperature is too high Ice cream mixture temperature is too warm The volume of the mixture is more than required measurements Choose a well-ventilated area with temperatures above 60°F (16°C) and below 90°F (32°C) Use refrigerated mixture and make sure that your pre-mixture does not go over top dasher of the churn blade Ice cream maker compressor does not run when operation of the unit has been resumed The ice cream maker has entered a three minute compressor lockout This three minute time delay helps extend the life of the compressor. Once it elapses, the compressor will engage and the ice cream maker will start cooling again. Contact Whynter Service Department. Ingredients were warm or at room temperature before placing in the bowl The ice cream maker lid was opened and closed too many times during the freezing process. The freezing bowl has a thick coating of ice on the walls. Use refrigerated mixture that does not go over top dasher of the churn blade Refrain from opening the lid many times After washing, dry completely prior to placing back in ice cream maker Ice cream maker stops churning before ice cream is ready Too much mix-in ingredients are added causing the churn blade to jam Mix-in ingredients, such as chocolate chips or chopped nuts, added too soon Wait until ice cream mixture is thickened or frozen before adding ingredients Low-fat ice cream is being made Too much water in the mixture Sugar in the mixture is not dissolved Use whole milk or buttermilk instead of nonfat milk Put the sugar on the fruit and let it melt in the fruit's juices instead of using syrup Make sure sugar is well-dissolved During shipping, due to pressure, the mixing bowl may have been suctioned into the freezing canister To remove, firmly pull the bucket up and out Some user tips for your ice cream maker: Our freezing bowl is approved for food safety. Since aluminum can react to acidic solutions, the recommendation is to not store acidic foods in the freezing bowl for long periods. We recommend removing any acidic frozen mixtures from the freezing bowl and store them in plastic containers. Please note that our ice cream makers are a self-contained, compressor operated unit which no pre-freezing and salt required. All you need to do is to put the refrigerated mixture into the removable mixing bowl and the unit will freeze the mixture. Optional: Freeze newly-made ice cream for about 4 hours before serving. This is also known as "ripening" Safety Precautions APPLIANCE SAFETY Your safety and the safety of others is very important to us. To reduce the risk of fire, electrical shock, or injury when using your appliance, follow these basic precautions: This is the Safety Alert Symbol. This symbol alerts you to potential hazards that may result in serious injury. All safety messages will follow the Safety Alert Symbol and either the words "DANGER" or "WARNING". Danger means that failure to heed this safety statement may result in severe injury or death. Caution means that failure to heed this safety statement may result in moderate injury, or property or equipment damage. All safety messages will alert you to know what the potential hazard is, tell you how to reduce the chance of injury, and let you know what can happen if the instructions are not followed. IMPORTANT SAFEGUIDES Before the appliance is used, it must be properly positioned and installed as described in this manual, please read the manual carefully. To reduce the risk of fire, electrical shock or injury when using the appliance, follow basic precaution, including the following: Plug into a grounded 3-prong outlet, do not remove grounding prong, do not use an adapter, and do not use an extension cord. Do not use if the power supply cord is damaged. If damaged, it must be replaced by a qualified electrician. It is recommended that a separate circuit, serving only your appliance be provided. Use receptacles that cannot be turned off by a switch or pull chain. Never clean appliance parts with flammable fluids or harsh chemicals. These fumes can create a fire hazard or explosion. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of the appliance or any other appliance. Before proceeding with cleaning and maintenance operations, make sure to unplug the appliance. Do not connect or disconnect the electric plug with wet hands. To protect against risk of electric shock, do not pour water on cord, plug and ventilation, immerse the appliance in water or any other liquid. Do not attempt to repair or replace any part of your appliance unless it is specifically recommended in this manual. All other servicing should be referred to a qualified technician. FOLLOW WARNING CALL OUTS BELOW ONLY WHEN APPLICABLE TO YOUR MODEL. It is important for the appliance to be leveled in order to work properly. For a stable installation, make sure the appliance is placed on a flat, level and solid surface. When positioning or moving the appliance ensure that it is not turned upside down or greater than 45° or more off level. To ensure proper ventilation for your appliance, the air vents of the appliance must be completely unobstructed. Choose a well-ventilated area with temperatures above 60°F (16°C) and below 90°F (32°C) This appliance must be installed in an area protected from the element, such as wind, rain, water spray or debris. This appliance is intended for use by young children or physically-challenged persons without supervision/assistance. Young children must be supervised to ensure safety around this or any appliance. Never pull the cord to disconnect it from the outlet. Grasp the plug and pull it from the outlet. Never lift, carry or drag the appliance by the power cord. This appliance is designed for household, non-commercial use only. Any other use will void the warranty. Do not insert any foreign objects into the appliance. Do not power on the appliance before the removable mixing bowl and transparent lid are installed properly This is a self-contained ice cream maker and no pre-freezing is needed. Do not use pre-frozen ingredients as it can cause the mixture to freeze before ice cream is made. Do not remove the churn blade when the appliance is freezing. Avoid placing any objects on top of the appliance. This is an electrical appliance, to avoid injury from electrical shock do not operate the unit with wet hands, while standing on a wet surface or while standing in water. Do not use outdoors or in wet conditions. Do not plug into the power outlet before set up is completed. WWW.WHYNTER.COM Download manualHere you can download full pdf version of manual, it may contain additional safety instructions, warranty information, FCC rules, etc.Download Whynter ICM-2015B - Ice Cream Maker Manual Whynter 2.1 Quart Upright Ice Cream Maker with Stainless Steel Bowl Congratulations on your new Whynter product. To ensure proper operation, please read this Instruction Manual carefully before using this product. Keep this manual in a safe place for future reference. Model # : ICM-2015B INSTRUCTION MANUAL V.18.12.16-1627 Loading page 2... Loading page 3... Loading page 4... Loading page 5... Loading page 6... Loading page 7... Loading page 8... Loading page 9... Loading page 10... Loading page 11... Loading page 12... Loading page 13... Loading page 14... Page 2 of www.russellobbs.com/23604/Register online for an EXTRA year guaranteeVisit www.russellobbs.co.uk/productregister/ You must register within 28 days of purchase Loading page 2... Loading page 3... Loading page 4... Loading page 5... Loading page 6... Loading page 7... Loading page 8... Page 3