I'm not a robot

59Chapter 8Call Forwarding your callsYou can call forward your calls if you do want your calls to go to CallPilot immediately, without ringing at your extension. For example, you can set up Call Forwarding if you are not going to be in the office and you do not want your ringing phone to disturb your colleagues, or if you do not want to take calls while you are working. While Call Forward is on, callers can leave a message for you without having to wait for the phone to ring several times.This chapter explains the following ways you can forward your calls:Call Forwarding your calls to your mailboxSetting up Call Forward remotelyCall Forward with Caller IDCall Forwarding your calls to your mailboxTo forward incoming calls to your mailbox, press .To cancel Call Forward, do one of the following:press againpress press press CANCELCallPilot Reference GuidePage 282 Chapter 10 Off-premise Message NotificationStart:CHNGNEXTStop:CHNGNEXT21Press NEXT or to accept the start time that you entered orpress CHNG or to change the start time.22Press NEXT or to accept the stop time that you entered orpress CHNG or to change the stop time.Msg type: new23Press OK or to be notified when you receive a new messageCHNGOKorpress CHNG or to be notified only when you receive an urgentmessage.Msg notify24Press to end the session.ADMIN SELECTThe Nortel Networks Corporation manufactures and distributes several different phone systems designed for use at businesses, both large and small. All of their systems' functions work similarly to be easy-to-use in general, and also to make them easy for anyone who is familiar with any particular one to perform similar functions on another. A function common to all Nortel phone systems is the ability to get the last incoming call, and the process to do so is simple. Hang up the Nortel phone receiver. The display window will be in call mode if the receiver is off of the hook, and the mode will not show incoming calls in the display window. Press the "Msg/Inbox" key on the Nortel phone. Incoming calls are displayed in a list in the display window. Pressing this key will bring up the most recent incoming call. Press the "Up/Down" navigation buttons to move through the incoming call list. There is a chance that the first call displayed when you press the "Msg/Inbox" key is not the last incoming call. In this case, scroll through the incoming call list to find most recent call by identifying it with the call-time display in the display window.Forwarding your callsPressand enter the number of the internal telephone to which youwant your calls forwarded.Use Line Redirection to forward calls outside the system.Line redirection takes precedence over Call Forward.Canceling Call ForwardPress.Using Call Forward at your telephoneWhen you use, all calls go to the destination you select, regardlessTip- If your Norstar set is a member of a Hunt Group, the Call Forward all calls setting is overridden by the HuntGroup routing for Hunt Group calls. For more information about Hunt Groups, see Programming Hunt Groups on page 171.If the telephone to which you forwarded your calls does not have the same external lines as your telephone, the forwarded calls appear on intercom buttons.If a call is forwarded, it does not ring. However, the line indicator flashes on the telephone. You can answer the call by pressing the button next to the flashing indicator.Tip - If you are one of a group of people who regularly forward their calls to one another, be aware that it is possible to set up forward loops where a call is forwarded from one telephone to another in a circle, and is never answered anywhere.P0603544 02Compact ICS 6.1 System Coordinator GuidePage 2Backup programming overlays / 277Backup programming overlaysBusinessSeriesTerminalsProgrammingRecordNorstar Programming OverlayHeadingShowBackNext Nortel was a recognized leader in delivering communications capabilities that make the promise of Business Made Simple a reality. Nortel developed next-generation technologies, for both service provider and enterprise networks, to support multimedia and business-critical applications. Nortel's technologies were designed to help eliminate today's barriers to efficiency, speed and performance by simplifying networks and connecting people to the information they need, when they need it. At its peak, Nortel did business in more than 150 countries around the world. The Nortel Meridian M3904 phone supports up to 12 lines with 6 self-labeled, programmable line/feature keys and a 5-line, 24-character display. Equipped with excellent features and functions, such as Call Forward, the Nortel M3904 phone is a great option for your business office.The Call Forward feature allows you to direct your calls to ring another line (Directory Number). You cannot forward calls while your telephone is ringing.To forward your calls:Press the Forward key. The previously stored forward number appears, if one exists, and the screen displays Enter forward number.If desired, enter a new number. The existing number is automatically deleted. If you make a mistake, use the Delete key to delete the previous digit(s). Press Cancel to leave this screen without forwarding your telephone or changing the number.Press the Done key to activate Call Forward.To view the number that your calls are being forwarded to:Press the Check Forward (CheckFw) key.Press the Exit key to return to the previous screen. This action will leave Call Forward active.To cancel Call Forward:Press the Check Forward (CheckFw) key.Press the Cancel Forward (CanclFw) key.Internal Call Forward allows only calls originating at internal DNs to ring at another DN. Calls originating outside your Meridian 1 system will still ring at your telephone. You cannot forward calls while your telephone is ringing.To forward your internal calls:Press the Internal Call Forward (IntForward) key, or lift the handset and enter the Internal Call Forward Activate FFC (Flexible Feature Code).Dial the DN where you want to forward your calls.Press the Internal Call Forward (IntForward) key.To cancel Internal Call Forward:Press the Internal Call Forward (IntForward) key, or lift the handset and enter the Internal Call Forward Deactivate FFC.To reinstate Internal Call Forward to the same number:Press the Internal Call Forward (IntForward) key twice.Remote Call Forward feature allows you (from any telephone other than your own) to forward your calls to any telephone.To activate Remote Call Forward:Lift the handset.If you call from a telephone outside the system, first dial your Direct Inward System Access number and wait for dial tone.Dial the Remote Call Forward Activate FFC to activate the feature.Dial your Station Control Password.Dial your DN. You get a dial tone before you dial your number.Dial the number where you want to forward your calls. If you forward calls to an invalid number, you receive a fast busy tone.Press the # key.Note: To forward calls to a previous call forward telephone number, skip step six above.To cancel Remote Call Forward:Lift the handset.If you call from a telephone outside the system, first dial your Direct Inward System Access number and wait for dial tone.Dial the Remote call forward Deactivate FFC.Dial your Station Control Password.Dial your DN. You get a dial tone before you dial your number.Press the # key.Note: When you use the Remote Call Forward feature to change the number to which your calls are being forwarded, this information is not updated on the display of your M3900 Series telephone. The telephones display will continue to show the last call forward number that was entered from the telephone using the Call Forward feature.And that is how you use Call Forward on the Nortel M3904 phone. For further questions, please see your System Administrator.If youre looking for replacement Nortel phones or other new and refurbished telephone equipment for your business office, please visit Startechtel.com or call 800-564-8045. We are always happy to help you find the right business phones and systems for you. Find, follow, & like us on Facebook, Twitter, LinkedIn, and Pinterest.Summary Related Posts Tags: Call Forward, Follow along, Forwarding Calls, Guide, Nortel M3904 Phone, Steps for call forward feature 4Press the Forwrd softkey.Once you complete setting up the forwarding, the display on your phone set briefly changes to indicate that calls are now forwarded. The telephone icon next to the line button becomes hollow.Note: If there is more than one user logged into the i2004 Internet Telephone then you must press the line button next to the line you want to forward. Or, press the Ok softkey to forward the primary line.Tip: You can still place outgoing calls, even though your line is forwarded to another location.Canceling a forwarded callTo cancel call forwarding on your lineTip: If you are logged into multiple i2004 Internet Telephones, every line associated with you will have call forwarding canceled.1Press the Servcs softkey.2Highlight the Call Forwarding option and press the Select softkey.3Press the Ok softkey to cancel forwarding for the primary line. If there is more than one user logged in then you will be prompted to press the line button next to the line that you wish to cancel forwarding.When you press the forwarded line button, call forwarding is canceled immediately.i2004 Internet Telephone User GuidePage 26Press the Send softkey. A confirmation message appears.Handling incoming instant messagesWhen your i2004 Internet Telephone beeps to alert you of a new instant message (IM), you can1Use the navigation buttons to scroll through the IM text.2Use the Detail softkey to view details about the IMPress Call to call the sender of the IM.Press the Reply softkey to reply to an IM. Enter the desired message using the alphanumeric input mode, and select the Send softkey, or Cancel to return to the previous screen.3Use the Prev and Next softkeys if you have more than one IM to view.4Press the Cancel softkey to clear all IM messages.Call forwardYou can forward your calls to other locations with your i2004 Internet Telephone Call Forwarding feature.Tip: If you are logged into multiple i2004 Internet Telephones, every line associated with you will have call forwarding enabled.Forwarding a callTo forward your calls to another location1Press the Servcs softkey.2Highlight the Call Forward option and press the Select softkey. (See Note below if there is more than one user logged in.)3Enter the destination address. Or, press an inbox, outbox or address book quick button and select an entry from the list.NN10042-113Page 3After pressing the Ok softkey on the last configuration parameter, you will see a message "Locating Server".Where to go nextAfter the i2004 Internet Telephone has successfully located the server, follow the instructions in the following table.Table 11 Initializing options after setting parametersIf ...Then ....the telephone successfully connects to thego to Step 1: Enter an activation key onserver and the display prompts you to enterpage 6.an activation keyActivate06/069:31 amEnter Activation KeyAnd Press Ok>OkAlphathe telephone successfully connects to theyou are ready to use your telephone. Goserver and the idle display screen appearsto Chapter 2, Introducing the i2004TomInternet Telephone, on page 13.OnHook06/069:31 amWelcomeViewServcsDNDConfigNN10042-113Page 4ValueDefinitionSET IPIP address of your i2004Internet Telephone providedby your systemadministratorNETMSKSubnet Mask provided byyour system administratorDefault gateway IP networkaddress provided by yoursystem administratorPrimary server (IP ClientManager or SIP MultimediaPC Client) IP addressS1 PORT5000Primary server portS1 ACTION1Primary action code (enter 1for UNIStim)S1 RETRY Count1Primary retry countSecondary server (IP ClientManager or SIP MultimediaPC Client) IP addressNote: If you do not know thesecondary IP address, usethe primary IP address forthe secondary address.S2 Port5000Secondary server portNote: If you do not know thesecondary port, use theprimary port.S2 ACTION1Secondary action code(enter 1 for UNIStim)1Secondary retry countVLAN (0=No, 1=Yes)0QoS 802.1a VLAN TagService (applies to i2004with firmware versionxxxxB30Warning: The VLAN parameter should never be selected unless the underlying network switches have been configured to filter on VLAN IDs. Otherwise, the i2004 may fail to work properly.i2004 Internet Telephone User GuidePage 5If your network does not support DHCP1Enter a 0 on the dialpad, to indicate that DHCP is not supported.2Follow the prompts to set all necessary parameters as described in Table 10.NN10042-113Page 6Setting DHCP parameters 79Table 9 Setting DHCP configuration parametersDHCP (enable)1YesDHCP (full or partial)1PartialS1IPPrimary server (IP ClientManager or SIP MultimediaPC Client) IP addressS1PORT5000Primary server portS11Primary action code (mustbe set to 1)S1RETRY Count1Primary retry countS2IPSecondary server (IP ClientManager or SIP MultimediaPC Client) IP addressNote: If you do not know thesecondary IP address, usethe primary IP address forthe secondary address.S2Port5000Secondary server portNote: If you do not know thesecondary port, use theprimary port.S2ACTION1Secondary action code(must be set to 1)1Secondary retry countVLAN (0=No, 1=Yes)0QoS 802.1q VLAN TagService (applies to i2004with firmware versionxxxxB30Warning: The VLAN parameter should never be selected unless the underlying network switches have been configured to filter on VLAN IDs. Otherwise, the i2004 may fail to work properly.After pressing the Ok softkey on the last configuration parameter, you will see a message "Locating Server".i2004 Internet Telephone User Guide Says Forward, Call Forward Button is showing Call forwarded via Feature 4. Feature #4 doesn't says denied in admin. Pressing the button with the forward logo beside id, and says denied in admin. Why I thought it was set lock full, but its not. Sep 22, 2002 14,246 Toronto, Canada Well the only 3 ways to cancel a Feature 4 method of forwarding:Press the Softkey by the display that says CANCELPress the Softkey by the display that says something like FWD#.. and then press CANCELPress Press FEATURE # 4Because it is software ver 1.0 we know it's not an External forward, which come to think of it now, that would the method that shows "FWD#.."By pressing FWD#.. it would show you the external #. So we are down to Press the Softkey by the display that says CANCELPress FEATURE # 4 Is there anything else on the phone that does not work such as all or some of the other buttons including the dial pad?FEATURE * 0 INTERCOM is button inquiry (press every button to see what it is actually programmed as)FEATURE 805 is to test everything on the phone"Pressing the button with the forward logo"There is no such logo that I recall, unless custom made somewhere but the button inquiry above might tell the truth. To be sure, and in case button label issue, the FEATURE key is above the HOLD key. Reboot the phone - unplug mod cord from the bottom of phone, or the wall jack.If still an issue, turn Set Relocation on/Y (only if it is Off/N) in Systprog/FeatureSettings , move the jumper to another spare port and try again to cancel it.To see what port # the phone is using: FEATURE * 0 INTERCOM VIEW(or #) Rebooting system can usually clear some glitches. I cannot think of anything else. =----(((((((((----=Toronto, CanadaAdd me to LinkedIN Have you just tried swapping over the phone with another model?. Can you post a photo of the phone here?. Have you tried moving the call forward button to a spare one using Feature *3 etc?. I would also follow Curlycord's advice in rebooting the system in case it's got a little bit of corruption. Firebird Scrambler Nortel & Avaya Meridian 1 / Succession & BCM / Norstar Programmer Website = linkedin I had a problem similar to that a few years ago and found out the Line Redirection had been enabled on a couple of lines that did not appear on any set. Entering F#84 fixed the issue. Here is the Nortel instructions on hold to forward calls to another number from your Nortel Phone. Use these steps to forward calls when you are out. Forward Nortel Phone to another numberForwarding calls on your Nortel T7316e phone is a convenient feature that allows you to redirect your incoming calls to another extension within your phone system. This guide will walk you through the steps to set up and cancel call forwarding using the feature codes on your Nortel T7316e phone. Well also cover how to identify if your phone has the necessary Feature button programmed.For Onsite Nortel Support1-888-383-6286USA Nortel Networks Phone System SupportFORWARD NORTELThis is to forward a Nortel Phone to Another NumberIf you need to forward to an extension click hereForward Nortel T73316e PhoneIf youre trying to forward your Nortel Phone to an outside telephone number the steps you should follow are available for most carriers.On your Nortel T7316e Phone*72 to activate call forwarding, when you hear two short tones. At the tone, dial first Star followed by 72 followed by the outside telephone number where you want your calls forwarded to; when the call is answered, the feature has been activated. *73 to deactivate call forwarding.The Nortel T7316e Phone is most often a Line Telephone SystemTherefore you have to forward the Phone Lines unless you wish to forward your T71316 Phone to another extension then you follow these instructions. Here These dial codes have been used for decades by the carrier to control the path of Traditional Line Phone Systems!Did you knowLine Phone Systems are Still AvailableLearn about the official upgrades and Onsite Hybrids that use the same telephone wire as each phoneOf Nortel Phone Systems1-888-430-4041About Nortel T7316e Phone and SystemNortel was an amazing phone system made from the 80s, through the early 2000s, and sold mostly in the United States to small to medium size businesses like yours. These phone systems were designed to be user-friendly but highly rich in features. These systems had features that only large enterprise systems had at the time until these phone systems rolled out. These office phone systems were first marked as Meridian Phone, then Norstar Phone, and Finally the Nortel Phone.Nortel SupportGet Nortel Support from Nortel Help Desk Click herePhone System TechniciansNortel Support | Nortel Repair1-888-383-6286Norstar Meridian Nortel Nortel Networks T7316e Phone how to forwardAdditional Call Features6.Dial the number where you want to forward your calls. If you forward calls to an invalid number, you receive a fast busy tone.#7.Press the # Key.8.To forward calls to a previous call forward phone number, skip step six aboveTo cancel Remote Call Forward:1. Lift the handset on the remote phone that you are using to cancel forwarding of your calls.2.If you call from a phone outside the system, first dial your Direct Inward System Access number and wait for dial tone.3.Dial the Remote Call Forward Deactivate FFC.4. Dial your Station Control Password.5.Dial your Individual Line (DN). You get a dial tone before you dial your number.#6. Press the # Key. Nortel Networks 1150E is a versatile and robust IP desktop phone designed to enhance communication in a modern business environment. Targeting organizations of various sizes, this high-performance device combines advanced technology with a user-friendly interface, ensuring efficiency and productivity.One of the standout features of the 1150E is its support for Voice over IP (VoIP) technology. This capability enables clear and reliable voice communication over the internet, significantly reducing long-distance call costs. The 1150E is compatible with Nortel's Communication Server 1000, making it an ideal choice for businesses looking to implement or upgrade their IP telephony systems.The 1150E boasts a sleek and ergonomic design, featuring a large backlit graphical display that provides easy access to call information and navigation menus. The interface is intuitive, allowing users to manage calls and contacts without any hassle. The phone also offers multiple programmable keys, enabling quick access to frequently used features and contacts.Another significant characteristic of the 1150E is its support for advanced multimedia applications. This phone isn't just about voice; it also facilitates video conferencing and messaging. With its integrated support for various collaboration tools, users can seamlessly integrate voice calls with video and instant messaging, which is vital in today's fast-paced business world.Security is also a key focus in the design of the 1150E. It supports secure protocols such as SRTP and HTTPS, protecting the integrity and confidentiality of communications. This is increasingly important as businesses face evolving cybersecurity threats.Additionally, the 1150E includes features such as a speakerphone, headset compatibility, and wideband audio for enhanced sound quality during calls. With programmable soft keys and a user-friendly directory, the device streamlines the calling process, catering to the needs of busy professionals.In summary, the Nortel Networks 1150E IP phone combines essential communication features with advanced technologies, making it a reliable choice for any organization. Its VoIP support, multimedia capabilities, security features, and ease of use contribute to its reputation as a powerful tool for improving workplace communication. Whether for direct calls, conferencing, or collaboration, the 1150E remains a valuable asset in the modern office setting. Are you looking to do it from the phone? From the NTP's:To forward all calls from a Meridian 1 proprietary (digital)telephone:1 Press Forward.2 Dial the number where calls are to be forwarded.3 Press Forward.To cancel Call Forward All Calls: Press Forward. To forward calls from an analog (500/2500 type) telephone:1 Lift the handset and dial SPRE 74or lift the handset and dial #1 (2500 telephone)or lift the handset and dial the Call Forward Allowed FFC.2 Dial the number where calls are to be forwarded.3 Hang up. Remotely you can just rebuild that key as cfw 4 and it will take the forward off. JohnThePhoneGuy"If I can't fix it, it's not broke! I forgot to put this part in for analog.To cancel Call Forward All Calls: Lift the handset and dial SPRE 74or lift the handset and dial #1 (2500 telephone)or lift the handset and dial the Call Forward Deny FFC. I wouldn't delete the CFW key when its active, you could corrupt the DN if the system doesn't rewrite the memory registers correctly. If you're in house, use the remote call forward feature. It may take about 15 minutes to set it up if its not already active, but the NTP's are very good in stepping you through it. Share copy and redistribute the material in any medium or format for any purpose, even commercially. Adapt remix, transform, and build upon the material for any purpose, even commercially. The licensor cannot revoke these freedoms as long as you follow the license terms. Attribution You must give appropriate credit , provide a link to the license, and indicate if changes were made . You may do so in any reasonable manner, but not in any way that suggests the licensor endorses you or your use. ShareAlike If you remix, transform, or build upon the material, you must distribute your contributions under the same license as the original. No additional restrictions You may not apply legal terms or technological measures that legally restrict others from doing anything the license permits. You do not have to comply with the license for elements of the material in the public domain or where your use is permitted by an applicable exception or limitation . No warranties are given. The license may not give you all of the permissions necessary for your intended use. For example, other rights such as publicity, privacy, or moral rights may limit how you use the material. Note: Requires a high level of Nortel voicemail software and it ties up 2 lines for the duration of the call.Instructions: Press Call Forward (or Feature 4), dial external code such as 9, dial external numberTo Cancel Call Forward, see CANCEL on the phones display, or press Feature # 4In most cases, a telephone technician needs to program this feature. 4a) Voicemail Message NotificationAllows a voice mailbox to call an external phone number, to alert a user that they have a voicemail message.Instructions:Log into your mailbox, press Admin (or 8), Press 6-Admin (or 1) to setup your phone number-Select (or 2) to turn on or off Message NotificationWhen you receive the call press 1 to check the messagesIn most cases, a telephone technician needs to program this feature Note: both options above leave you open to Toll FraudYou MUST use a 6 to 8-digit password that is complexDo not use passwords such as 1111, 1234 or 0000 Additionally, you may want to record a temporary greeting in your General Delivery Mailbox or on your Voicemail Auto Attendant greeting. The Nortel M3904 phone is an ideal addition to any office phone system. Boasting a smart design including six Programmable Line (DN)/Feature Keys (self-labeled) with two features/lines configured on each key, this quality business phone offers convenience and simplicity for your employees.Call ForwardOne of its helpful features is Call Forward. This allows you to direct your calls to ring at another line/ directory number (DN). Please note that you cannot forward calls while your telephone is ringing.To forward your calls, begin by pressing the Forward Key. The previously stored forward number appears (if applicable) and the screen displays Enter forward number. If desired, enter a new number (the existing number will be deleted automatically). If you make a mistake, use the Delete Key to delete the previous digit(s). Press Cancel to leave this screen without forwarding your telephone or changing the number. Press the Done Key to activate Call Forward.To view the number that your calls are being forwarded to, press the Check Forward (CheckFw) Key. The number will be displayed on the screen. Press the Exit Key to return to the previous screen (Note: This will leave Call Forward active).To cancel Call Forward, press the Check Forward (CheckFw) Key, the press the Cancel Forward (CanclFw) Key.Internal Call ForwardThis feature allows only calls originating at internal DNs to ring at another DN. Calls originating outside of your Meridian 1 System will still ring at your telephone. Again, please note that you cannot forward calls while your telephone is ringing.Begin by pressing the Internal Call Forward (IntForward) Key. Next, dial the DN where you want to forward your calls. Lastly, press the Internal Call Forward Key.To cancel Internal Call Forward, press the Internal Call Forward (IntForward) Key.To reinstate the Internal Call Forward to the same number, press the Internal Call Forward (IntForward) Key twice.Please note: The Meridian SL-100 uses the Call Forward Busy/Dont Answer Internal/External FAC. This allows Meridian SL-100 user to:Forward an incoming call which originated internally from a DN in the same customer group as you.Forward an incoming call which originated externally from a DN out of your customer group to a DN outside your customer group.Remote Call ForwardThis feature allows you (from any telephone other than your own) to forward your calls to any telephone. To use this feature you must have a Call Forward Key configured on your telephone.Please note: On the Meridian SL-100, dial the Remote Access Directory Number. You are prompted to enter the directory number of your telephone, your PIN, and the Call Forwarding authorization code. Follow the prompts to activate, deactivate, or change call forwarding to a new destination.To activate Remote Call Forward, start by lifting the handset. If you call from a telephone outside the system, first dial your Direct Inward System Access number and wait for dial tone. Next, dial the to activate the feature. Then, dial your Station Control Password. You should hear a dial tone, and then you may dial your DN. Next, dial the number where you want to forward your calls (if you would like to forward calls to a previous call forward number, skip this step). If you forward calls to an invalid number, you will hear a fast busy tone. Lastly, press the # Key.To cancel Remote Call Forward, lift the handset. If you call from a telephone outside the system, first dial your Direct Inward System Access number and wait for the dial tone. Next, dial the Remote Call Forward Deactivate FFC. Then, dial your Station Control Password, wait for a dial tone, and then dial your DN. Lastly, press the # Key.And that is how you use the Call Forward features on the Nortel M3904 phone. For the best prices on the Nortel M3904 phone and other new and refurbished business phones, please visit Startechtel.com or call 800-564-8045. For the latest news and updates, connect with us on Facebook, Google+, Twitter, LinkedIn, and Pinterest.Summary Related Posts Tags: Call Forward, Call Forwarding, How to, Nortel M3904 Phone, Nortel Networks, Phone Manual 77Telephone Features Programming GuideChapter 6Forward your callsIf you leave your desk but want to receive calls at another location, you can forward your calls to an internal or external telephone. You can also use Call Forward to automatically forward calls to a voice mail system.Call ForwardWhen you use the Call Forward feature code, all calls go to the destination you select, regardless of Forward on busy (CFB) and Forward no answer (CFNA) feature programming. To forward calls:1Press .2Enter the number of the telephone to which you want your calls forwarded. To forward your calls to an external destination you must enter the route plus the dialing digits of the external telephone. For example, if you need to dial 9 for external calls, then you must enter 9 plus the dialing digits to forward your calls to an external number.Alternatively, you can use Line Redirection to forward calls outside the system. Line Redirection takes priority over Call Forward.Cancel Call ForwardPress to cancel Call Forward.If the telephone to which you forwarded your calls does not have the same external lines as your telephone, the forwarded calls appear on intercom buttons.Forwarded calls do not ring but the line indicator flashes on the telephone. You can answer the call by pressing the button next to the flashing indicator.Override Call Forward When you call a person who has Call Forward to your extension, your call rings at that persons telephone.Note: If you set up forward loops from one telephone to another in a circle, this can result in unanswered calls at any location.

Nortel phone cancel call forward. How to cancel call forwarding on nortel networks phone. How to turn off call forwarding on nortel phone. Nortel phone remove call forward. How to forward calls on nortel networks phone. Nortel cancel call forward.